Digitouch

DIGITAKT OSC LAYOUT MADE FOR IPAD

🖊 **ADD THE DIGITAKT LAYOUT TO IOS / ANDROID DEVICE:**
GO TO ITUNES - YOUR DEVICE - FILE SHARING - DRAG THE *.OSC FILE INTO THE TOUCHOSC APP
ANDROID >>> HTTPS://HEXLER.NET/DOCS/TOUCHOSC-CONFIGURATION-LAYOUT-ADD-FROM-FILE

🔌 **TOUCHOSC CAN CONNECT USING OS X COREMIDI** NETWORK **- BRIDGE - USB C** OR **CAMERA CONNECTION KIT {IOS!}***

HTTPS://HEXLER.NET/DOCS/TOUCHOSC-GETTING-STARTED

📄 **OPEN ''TAKT 2.1B.TOUCHOSC'' ON YOUR IPAD** OR TABLET

💻 PLUG DIGITAKT USB TO PC/MAC _ (IF YOU WANT TO USE IPAD AS A WIRELESS CONTROLLER)
IPAD PRO 11 " / 12.9" USB C NEED USB C CABLE + OTG ADAPTER (NO CAMERA KIT REQUIRED)

🖋 **CONFIGURE YOUR MIDI STUDIO [OSX]**

🔧 **SET YOUR MACHINE** [PAGE 8]

⚫ **HAVE FUN!!**

DIGI⊶TOUCH
Digitakt layout version 2.1 B

+   ▲▲▲   🙂   ⠿   [DIGITAKT]   ◦

NOTE :
template resolution made for ipad _
iPad Pro 11 "+ 12.9" now supported!
*** midi config/Channel/ FX CONTROL CH = 15
% Minor change and graphics improvements
have fun!! BIO ♡

Richardf _8 ◢
digi-touch.tumblr.com
du { T O N Ξ
{ TAKT
rev 703_18

REV703

NO MIDI MESSAGES HERE

TAKT

**Master**

↕ = TRACKS VOLUME (1/8)   ▢ = PUSH 1-8

⋔ = GLOBAL MUTE AUDIO TRACKS (1/8)   ⌇ = MIDI TRACK (1/8)

Send 1

◑ = OVERDRIVE (TRACK 1/8)   ✳ = BIT REDUCTION (TRACK 1/8)

Compressor PATTERN VOLUME   *Compressor* THRESHOLD

C/D = COMPRESSOR DRY/WET MIX

ATK = COMPRESSOR ATTACK TIME   REL = COMPRESSOR RELEASE TIME

MUP = COMPRESSOR MAKEUP GAIN   RAT = COMPRESSOR RATIO

SCS = SIDECHAIN SOURCE   SCF = SIDECHAIN FILTER

Send 2

⌁∪ = REVERB SEND (TRACK 1/8)   ♩ = DELAY SEND (TRACK 1/8)

F X

↕ = REV AND DELAY PARAMETERS (FUNC+FLTR/AMP) FX CONTROL CH 15

⌁∪ = REVERB   ♩ = DELAY   ↕ = HPF (Y)   ↔ = LPF (X)

**SRC**

↕ = *T U N E* (TRACK 1 - 8)

↕↔ = SAMPLE SLOT (TRACK AUTO)

↕↔ = VELOCITY / LENGTH (TRACK AUTO)

↔ = LOOP POSITION (TRACK 1-8)*

↕ = START POSITION (TRACK 1/8) *

↕ = END (LENGTH) (TRACK 1/8) **

Filter + AMP

↕↔ = CUTOFF / RESONANCE (X + Y) - AUTO TRACK

↕ = ENV DEPTH - TRACK 1 / 8

↕ = FLTR PARAMETERS - AUTO TRACK

↕ = DECAY - TRACK 1 / 8

↕ = HOLD TIME - TRACK 1 / 8

↕ = ATTACK - TRACK 1 / 8

Lfo

♪

↕ = DESTINATION   ↕ = START PHASE

↕ = TRIG MODE   ↕ = WAVE

↕ = FADE IN/OUT   ↕ = MULTIPLIER BMP

↕ = DEPTH   ↕ = SPEED

☰   ▲

↕ = SAMPLE SLOT - TRACK 1 / 8   ↕ = TUNE - TRACK 1 / 8

↕ = LENGHT - TRACK 1 / 8   ↕ = PLAY MODE - TRACK 1 / 8

▲▲▲

↕ = **LFO DESTINATION**
↕ = *REVERB SEND*
↕ = **ENV. DEPTH**
↕ = **DECAY TIME**
↕ = **ATTACK TIME**

↕ = **LFO DEPTH**
↕ = *DELAY SEND*
↕ = **RESONANCE**
↕ = **FILTER FREQ**
↕ = **VELOCITY**

▢

PUSH

8X PADS   (TRACK 1/8)   FLT.T ✕   LFO.T ✕

↕ = **VOLUME** − TRACK 1 / 8 ***

↕ = **NOTE** − TRACK 1 / 8 ***

↕ = **PATTERN VOLUME** (CH AUTO)

KEYB

$\updownarrow\leftrightarrow$ = TUNE (X) + SSLOT (Y) - TRACK AUTO   NOTE = C#0 /// C3 (25-60)

Pattern Mode

BANK **A** | BANK **B** | BANK **C** | BANK **D**

PATTERN 1/16   PATTERN 17/32   PATTERN 33/48   PATTERN 48/64

☺ TIPS :

_ DIGITAKT MIDI OUTPUT

```
MIDI CONFIG/PORT CONFIG
------------------------------------------
OUTPUT CH *          TRK CH
ENCODER DEST         INT+EXT
TRIG DEST            INT+EXT
MUTE DEST            INT+EXT
PARAM OUTPUT         CC
RECEIVE NOTE         0
RECEIVE CC/NRPN      0
------------------------------------------
```

** IF YOU WANT THE MIDI RETURN IN AUTO CHANNEL -
YOU HAVE TO SELECT "AUTO CH" ON OUTPUT CHANNEL*

*NEW _ IPAD PRO 11" / 12.9" (2018) USB C NOW SUPPORTED!
USE A OTG ADAPTER TO PLUG ELEKTRON CABLE USB B-A TO
YOUR TABLET USB 3.1 (NO NEED CAMERA KIT!)
_ DISABLE IPAD "GESTURES" IN SETTING / GENERAL / MULTITASKING*

_ PROGRAM CH SETTING

" PATTERN MODE "

*** IN MIDI CONFIG/SYNC

```
TURN ON PROGRAM CH RECEIVE
TURN ON PROGRAM CH SEND
FX CONTROL CH           15
AUTO CHANNEL            14
```

** IN THE MIXER PAGE (2)
SELECT THE TRACK 14 ON DIGITAKT
TO BYPASS THE "AUTO CHANNEL"
(IF YOU NEED TO USE MUTE/UNMUTE ON MIDI CH 14)

☺ Credits :

**IDEA AND DESIGN BY RICHARDF**
2017 ≡ 2019

🎁 Addictionals Notes :

**THE TEMPLATE WILL BE UPDATE
IN THE FUTURE... STAY TUNED!**

BIO 🖤 🐺 cc ① = 💀

🍴 Links :

HTTPS://DIGI-TOYS.WIXSITE.COM/DIGITOUCH
HTTPS://WWW.ELEKTRONAUTS.COM
HTTPS://HEXLER.NET/SOFTWARE/TOUCHOSC

T A K T *digitakt osc layout*

HTTPS://DIGITOUCH.THREADLESS.COM/COLLECTIONS/DIGI/